

BIOS Release Notes

TITLE

SUBJECT:	MP32-AR0 BIOS Release Notes version F18g
System:	E252-P30-00 , G242-P30-JG , G242-P30-LT , G242-P31-00 , G242-P31-JG , G242-P32-QZ , MP32-AR0-JG , MP32-AR1-00 , MP32-AR2-00 , R152-P30-00 , R152-P30-JG , R272-P30-00 , R272-P30-JG , R272-P30-UL , R272-P31-JG , R272-P3A-PB , GR2134 , G242-P30-JG , G242-P31-00 , G242-P31-JG , R152-P30-ES-Ambdedded-001 , G242-001-LT , G242-P30-LT , G242-P31-LT , G492-PD0-00 , R272-P31-00 , R272-P32-00 , R272-P33-00 , R152-P31-00 , R152-P32-00 , G242-P33-00 , G242-P35-00 , G242-P36-00 , E252-P31-00

About This Release

Build Date: [2021/11/01](#)
BIOS Checksum: [0xC5001A97](#) (32M)
Release Owner: Yuan.Chen

BIOS Components/Contents

Processor stepping(s) supported: Ampere eMAG2 processors

System hardware configurations supported: MP32-AR0, MP32-AR1, MP32-AR2

OPROM version :

OPROM	Version
AST2500 VGA	1.10

Installation Notes

IMPORTANT NOTES:

- Please extract the zip file to a bootable diskette that use FAT/FAT32 format

BIOS UPDATE FOR Easy BIOS Refresh:

1. The system supports remotely update BIOS if BMC existent.
2. Please download the Easy BIOS Refresh User Guide from Gigabyte website, target system support page.

BIOS Version CHECK INSTRUCTIONS:

1. Power on system and press during POST
2. The bios version shows on the first main page

BIOS UPDATE INSTRUCTIONS FOR Web UI:

1. Connect BMC_IP by Internet browser.
2. Click Web-UI sub-page button "Update".
3. Select Firmware Type to ROM.
4. Use Command Shell.
5. cd to /RBU.
6. Select File Path to image.RBU.
7. Click Upload.

BIOS Release Notes

BIOS UPDATE INSTRUCTIONS FOR GbtUtility:

1. Please copy the BIOS_ZIP file to GbtUtility folder.
2. Use Command Shell.
3. cd to GbtUtility folder.
4. Execute "java -jar GbtUtility.jar -H BMC_IP update bios BIOS_ZIP 1".

Known Issues/Workarounds

Issues fixed in this version

F18g

(2021/11/01)

1. Update SRP 1.08b